Galiente

Equipment List (to be provided by Purchaser of talent)

House Sound System

<u>Equipment</u> <u>Make</u>	e/Model
------------------------------	---------

1 - 32-Channel x8x2 Stereo-Mix Console

6 - Stereo Amplifiers (4200 watts)

4 - Full Range 3-Way Speaker Cabinets containing:

High Frequency Horns Mid-Range Driver Low-End Driver

6 - Direct Input Boxes

3 - Wireless Handheld Microphones (Vocal)

4 - Wired Microphones (Vocals/Backup)

16 – Wired Microphones (Instrument/Horns)

15 – Boom Stands

8 - Straight Stands

Audio Snake with Split Signals

Stage Monitor System

1 24-Channel x8 Monitor Console

9 - Monitors with 15" Speaker & Horn with Stereo Power Amps

<u>Lighting System</u>

1 Twelve-Instrument Front Truss (Pars)

1 Eighteen-Instrument Rear Truss (Pars)

16-Channel Dimming System

2 - Follow Spotlights with Experienced Operators

Please Note: Moving Lights Are Always Welcome

Plus all necessary cords and adapters

Yamaha or equivalent

Yamaha P-2200 or equivalent

Apogee, JBL, Eastern Acoustic JF 500

or equivalent

Vega (UHF) or better Shure - SM 57 or 58 Shure – SM 57 or 58

Yamaha 2408 or equivalent Apogee, JBL, or equivalent Crown (200 Watts/Side) or equivalent

Caliente

Input List

Channel 1	Kick
Channel 2	Snare
Channel 3	Toms
Channel 4	Floor Tom
Channel 5	Cymbal
Channel 6	Lead Vocal

Channel 6 Lead Vocal / Downstage Center (Wireless)

Channel 7 Female vocal (Wireless)
Channel 8 Female vocal (Wireless)
Channel 9 Male (Bass) Vocal

Channel 10 Male (Guitar/Keyboard) Vocal

Channel 11 Male (Drum) Vocal
Channel 12 Male (Keyboard) Vocal
Channel 13 Keyboard Stage Left - DI
Channel 14 Keyboard Stage Left - DI
Channel 15 Keyboard Stage Right - DI
Channel 16 Keyboard Stage Right - DI

Channel 17
Channel 18
Channel 19
Channel 20
Bass - DI
Guitar - DI
Alto Saxophone
Tenor Saxophone

Channel 21 Trumpet Channel 22 Trombone Channel 23 Congas (Left) Channel 24 Congas (Right) Channel 25 Conga (Vocal) Channel 26 Tymbales (Left) Channel 27 Tymbales (Right) Channel 28 Tymbales (Vocal)

Channels 29 – 32 Spare

Caliente

Input List

Vocal microphones Four (4) Shure SM 58 or compatible

Two (2) wireless Shure SM 58 or compatible

Drum microphones Seven (7) Shure SM 57 or compatible / Beta 52 or 91 kick,

at least One (1) overhead SM 81

Trumpets One (1) SM 58 or SM 57

Trombone One (1) SM 58 or SM 57

Sax Two (2) SM 58 or SM 57

Microphone Stands Nineteen (19) with boom

Guitar One (1) D-Box

Bass One (1) D-Box

Keyboard Two (2) D-Box

Sequence Module Six (6) D-Box

Monitor Mix Seven (7) Six regular monitor sends & One headphone send

Monitors Nine or Ten (9 or 10) 12" or 15" wedge

Console Thirty-Two (32) channels minimum